









### Fresh Blends User Guide

The *Fresh Blends* recipe book has more than 200 recipes that you can prepare with your SignatureSeries blender. Use these charts to determine the appropriate pre-programmed blend cycle or speed:

#### Pre-Programmed Cycles

	Batters Sauces Dips Dressings
	Smoothies Ice Crush Milkshakes
	Ice Cream Frozen Yogurt
	Whole Juice
	Soups Syrups Fondues
	Pulse
	Stop



#### Manual Speed Control

The SignatureSeries touchpad gives you one-touch control over the blender speed. For *Fresh Blends* recipes indicating “Speed Up” or “Speed Down,” determine the appropriate button using the chart below.

If <i>Fresh Blends</i> says to use:	On the SignatureSeries press:
	— speed 1
speed 1	= speed 2
speed 2	= speed 2
speed 3	= speed 2
speed 4	≡ speed 3
speed 5	≡ speed 3
speed 6	≡ speed 4
speed 7	≡ speed 4
speed 8	≡ speed 5
speed 9	≡ speed 5

**Note:** Speed 1 on the SignatureSeries can be used to combine additional ingredients, to have greater control over texture, or to start with a slow blend.